



Wizzard Repair Products

Step by Step Instructions- STUCCO

For Photo or Video Step by Step Training, Visit our Website at wizzardrepairproducts.com/wrp-videos



Toll Free (888) 247-4052
P.O Box 7207 | Capistrano Beach, Ca 92624
info@wizzardrepairproducts.com
www.wizzardrepairproducts.com

Step 1 REMOVE ANY LOOSE DEBRIS.



Step 2 MIX EQUAL PARTS OF PART A LIQUID AND PART B. IT IS CRITICAL THAT IT IS EQUAL PARTS SO USE WIZZARD MIXING CUPS OR OTHER DEVICES THAT HAVE MEASUREMENTS ON IT. DO NOT OVER MIX AS IT WILL CREATE ADDITIONAL HEAT.



Step 3 APPLY THE MIXED WRP A AND B LIQUID BY BRUSH, DAUBER OR OTHER DEVICE UNTIL THERE IS A LIBERAL AMOUNT ON THE REPAIR AREA.



Step 4 MIX EQUAL PARTS OF PART A DOUGH (BROWN) WITH PART B DOUGH (WHITE) UNTIL DOUGH BECOMES 1 COLOR. TO TEST, MAKE A BALL OF DOUGH AND TEAR IN HALF, MIXTURE SHOULD BE THE SAME COLOR WITH NO STREAKS OF WHITE. FOR SMALL AMOUNTS, MIX BY HAND WEARING NITRILE GLOVES. LARGER AMOUNTS (½ GALLON OR MORE) CAN BE MIXED WITH THE WIZZARD MIXER AND A LOW SPEED DRILL. USE 1 OR 2 GALLON BUCKET, PLACE EQUAL AMOUNTS OF PART A AND B DOUGH THEN PULSE DRILL MOVING MIXER IN & OUT OF THE MIXTURE UNTIL FULLY MIXED, REMEMBER, NO HIGH SPEED.



Step 5 INSTALL DOUGH INTO AREA BEING REPAIRED, SLIGHTLY OVERFILLING IT. NOTE: MAKE SURE LIQUID HAS NOT DRIED OUT. IF SO, ADD MORE A AND B LIQUID MIXTURE. DOUGH CAN BE INSTALLED THICK AND DOES NOT HAVE TO BE LAYERED. THE THICKER THE DOUGH THE FASTER IT WILL CURE. YOU CAN MAKE A TEMPORARY FORM TO HOLD THE DOUGH IN PLACE BUT YOU SHOULD PUT WAX PAPER OR OTHER RELEASE MATERIAL ON THE FORM. ONLY LEAVE FORM IN PLACE LONG ENOUGH FOR DOUGH TO SET UP OR APPROXIMATELY 1 HOUR OR THE FORM WILL BECOME PART OF THE REPAIR AND WILL HAVE TO BE CUT OFF TO BE REMOVED.



Step 6 BETWEEN 5 AND 15 MINUTES BEFORE DOUGH SETS, TRIM OFF THE EXCESS DOUGH WITH WIZZARD'S CUT OFF KNIFE OR OTHER TOOL SO IT IS LEVEL OR SLIGHTLY UNDER THE EXISTING REPAIR SITE.



Step 7 TRANSFER SOME OF THE WIZZARD TOPPING AND TEXTURING COMPOUND INTO A MIXING CONTAINER AND ADD STUCCO PATCH UNTIL ALL DRY MATERIALS IS INCORPORATED WITH THE TOPPING MIX. MATERIAL SHOULD NOT BE DRY MAKE SURE IT IS STILL WET.



Step 8 APPLY THIS MIXTURE OVER THE REPAIRED AREA WITH A SPREADER, TROWL, SPONGE FLOAT AND CREATE TEXTURE TO MATCH. IF STUCCO IS SMOOTH OR SANTA BARBARA STYLE, YOU WILL NEED TO ADD # 20 OR 30 SAND INTO TOPPING AND TEXTURING COMPOUND INSTEAD OF STUCCO PATCH. WHEN COMPLETELY DRY, PRIME AND PAINT TO MATCH.



For Photo or Video Step by Step Training, Visit our Website at wizzardrepairproducts.com/wrp-videos

WizzardRepairProducts.com