



Wizzard Repair Products

Step by Step Instructions- WOOD

For Photo or Video Step by Step Training, Visit our Website at wizzardrepairproducts.com/wrp-videos



Toll Free (888) 247-4052
P.O Box 7207 | Capistrano Beach, Ca 92624
info@wizzardrepairproducts.com
www.wizzardrepairproducts.com

Step 1 REMOVE LOOSE DETERIORATED MATERIAL FROM THE REPAIR SITE.



Step 2 SPRAY REPAIR SITE WITH BIO CLEANER TO TREAT AND/OR PREVENTS MOLD. SINCE MOLD RETAINS MOISTURE WHICH FUNGUS STARTS TO GROW IN. SPRAY TO THE POINT OF RUN-OFF AND LET SOAK 5-10 MINUTES.



Step 3 SPRAY REPAIR SITE WITH MIXED FUNGICIDE TO TREAT OR PREVENT FUNGUS. FUNGUS EATS WOOD FIBERS. USE 3 OZ. FOR 16 OZ. BOTTLE OR 1 LB PER GALLON. STIR OR MIX UNTIL CLEAR. SPRAY UNTIL POINT OF RUN-OFF. WAIT 10-15 MINUTES FOR THE NEXT STEP.



Step 4 INSTALL COBRA RODS, (COPPER BORATE RODS) FOR EXTENDED PROTECTION FOR FUNGUS & TERMITES.



Step 5 MIX EQUAL PARTS OF CLEAR LIQUID A WITH HONEY COLORED LIQUID B TOGETHER AND COAT THE REPAIR SITE TO FORTIFY WOOD AND PROVIDE THE BOND ON THE REPAIR SITE WITHIN 30 MINUTES OR LESS. THEN GO TO THE NEXT STEP.



Step 6 MIX EQUAL PARTS OF PART A DOUGH (BROWN) WITH PART B DOUGH (WHITE) UNTIL DOUGH BECOMES 1 COLOR. TO TEST, MAKE A BALL OF DOUGH AND TEAR IN HALF, MIXTURE SHOULD BE THE SAME COLOR WITH NO STREAKS OF WHITE. FOR SMALL AMOUNTS, MIX BY HAND WEARING NITRILE GLOVES. LARGER AMOUNTS (½ GALLON OR MORE) CAN BE MIXED WITH THE WIZZARD MIXER AND A LOW SPEED DRILL. USE 1 OR 2 GALLON BUCKET, PLACE EQUAL AMOUNTS OF PART A AND B DOUGH THEN PULSE DRILL MOVING MIXER IN & OUT OF THE MIXTURE UNTIL FULLY MIXED, REMEMBER, NO HIGH SPEED.



Step 7 PACK BLENDED DOUGH INTO THE AREA YOU ARE REPAIRING SLIGHTLY OVER FILLING AND LET IT SIT 10-20 MINUTES THEN TRIM FLUSH WITH A KNIFE TO LEVEL THE SURROUNDING AREAS. DOUGH NEEDS TO BE SOFT, USE EXCESS DOUGH YOU TRIMMED IN THE OTHER PREPARED AREAS THAT HAS BEEN COATED WITH THE LIQUID A AND B MIXTURE. IF DOUGH GETS HARD, YOU WILL HAVE TO WAIT UNTIL IT CURES 3-8 HOURS DEPENDING ON THE REGION. WHEN FULLY CURED, YOU CAN SAND FLUSH.



Step 8 MIX TOPPING COMPOUND WITH SMOOTH POWDER TO CONSISTENCY OF PEANUT BUTTER OR THICKER AND APPLY OVER REPAIR SITE TO CREATE A SMOOTH TRANSITION TO THE SURROUNDING SURFACES. IF YOUR SURFACE IS MEDIUM OR ROUGH, ADD TO THE ABOVE MIXTURE & MEDIUM OR COARSE POWDER AND APPLY A SECOND COAT. THEN USE TRIANGLE SHAPED TEXTURE TOOL, BRUSH, OR OTHER TOOL TO CREATE FINISHED LOOK.



Step 9 STAIN OR PRIME AND PAINT REPAIR SITE

For Photo or Video Step by Step Training, Visit our Website at wizzardrepairproducts.com/wrp-videos

WizzardRepairProducts.com